



TIP: Combine the Shoreline and Grasslands Collections to create an immersive seaside oasis.

WHIRLER

PLAY ZONES

- 0 - 4
- 5 - 8
- 9 +

HIGHLIGHTS

Bring surrounding play features to life by spinning the Whirler's disk. Waterplay's Action Activators™ are the perfect blend of play value and water conservation.

WATER DISPLAY

.....
n/a



interactive



360° rotation



water smart

PRODUCT COLLECTION

Shoreline

COLOURS

Available with a beige or white post, and an orange acrylic plate.