



TAKE AIM



**DESIGN TIP:** This product is easily retrofitted into existing play environments.



## CRITTER 1

### PLAY ZONES

0 - 4

5 - 8

9 +

### HIGHLIGHTS

Grab hold of the Critter's antennae and use its vertical and horizontal movement to send water spray up, down, and from side to side. Pair with another Critter spray cannon to create a high action play experience.

#### WATER DISPLAY

spray effect



high action



interactive



rotation

#### PRODUCT COLLECTION

Grasslands

#### COLOURS

As shown in illustration