



SNEAKY SOAKER 3

PLAY ZONES

0 - 4

5 - 8

9 +

HIGHLIGHTS

Keep waterplayers on their toes with the Sneaky Soaker 3. Its bell-shaped tipping buckets spill and dump water at random intervals to create bursts of excitement on the play pad.

WATER DISPLAY

spray and splash effect



big splash



high action

PRODUCT COLLECTION

Kaleidoscope, Play Pals

COLOURS

See Waterplay Colour Collections