



PLAY ZONES



HIGHLIGHTS

Grab hold of the Critter's antennae and use its vertical and horizontal movement to send water spray up, down, and from side to side. Pair with another Critter spray cannon to create a high action play experience.

WATER DISPLAY

spray effect

waterplay[®] solutions corp.

high action interactive rotation

CRITTER 2

PRODUCT COLLECTION

Grasslands COLOURS As shown in illustration

1.800.590.5552 (USA & CAN) | +1 (250) 712.3393 (INTL) info@waterplay.com | www.waterplay.com

For full product specifications, please refer to component written specification document. Due to our continuing product improvement program, Waterplay[®] Solutions Corp. reserves the right to change specifications without notice. All plans & designs at all times remain the property of Waterplay or are used under license and cannot be used or reproduced without written permission.