



# **ENCORE** 0010-1428

**PRODUCT LINE** Freestanding Play

**CATEGORY** Soakers & Spinners

# **PLAY OPPORTUNITIES**

Water creates a gentle clapping sound as it spins the Encore's flipping plate and splashes onto the play pad below. A stunning play feature, the translucent flipper plate creates an eye catching spectacle in the sunlight.





# **PLAY-BASED LEARNING**



Play is fundamental in childhood development, health and wellbeing. Waterplay products are designed using research that supports cognitive, social and emotional, creative and physical growth. The above icons represent the leading attributes associated with this play feature.





## playPHASE™

Detachable Mounting System

## INSTALLATION

Zero-depth + Wading Pool

#### WATER EFFECT

Shower

#### waterplay<sup>®</sup> solutions corp.

1.800.590.5552 (USA & CAN) | +1 (250) 712.3393 (INTL) info@waterplay.com | www.waterplay.com

For full product specification details, please refer to the product specification document. Due to our continuing product improvement program, Waterplay<sup>®</sup> Solutions Corp. reserves the right to change the product specifications without notice. All product designs at all times remain the property of Waterplay or are used under license and cannot be used or reproduced without written permission.