



Optimize water use and maximize play value with Waterplay's on demand button activators. A perfect solutions for reducing water consumption while creating a dynamic play experience. **TWIST** to start the flow of water.

See Specification Sheet for product data.

## **WHIRLER**

0010-3054

**PRODUCT LINE** Freestanding Play, Water Management

**CATEGORY** 

Activators, Nature, Nautical

## PLAY OPPORTUNITIES

Bring surrounding play features to life by spinning the Whirler's disk. Waterplay's Action Activators™ are the perfect blend of play value and water conservation.





## PLAY-BASED LEARNING









**COGNITIVE** 

SOCIAL

**PHYSICAL** 

**CREATIVE** 

Play is fundamental in childhood development, health and wellbeing. Waterplay products are designed using research that supports cognitive, social and emotional, creative and physical growth. The above icons represent the leading attributes associated with this play feature.

**PLAY ZONES** 

**DEVELOPMENT** 

**DISCOVERY** 

**EXPLORATION** 

**ADVENTURE** 

playPHASE™

Detachable Mounting System

**INSTALLATION** 

Zero-depth

N/A

waterplay® solutions corp.

1.800.590.5552 (USA & CAN) | +1 (250) 712.3393 (INTL) info@waterplay.com | www.waterplay.com